


# Zoom 6000 System Diagram



\*T = Tele  
 \*\* Included with UltraZoom  
 \*\*\* Not Used with Internal Coaxial